

## HouseAndGardenFlags.com 973-697-8262

## Assembly instructions for 2-piece house flag pole 23958

## Parts included:





- 1- half of a wooden pole with a wooden knob on one end and a metal ferule at the other end
- 2- half of a wooden pole with an open end without a wooden knob
- 3- two screws in the metal ferule with one of them loose
- 4- a hard clear plastic tube sleeve
- 5- on the knob end: one full ring with a white cord and a metal clip; one thicker open ring
- 6- on the open end: one full ring with a white cord, two thicker open rings

## **Directions:**

You will need a small Phillips screwdriver.



- 1- Remove the plastic sleeve from the open-ended pole, then remove the loose screw from the metal ferule.
- 2- Insert the open-ended wooden pole into the metal ferule.
- 3- Insert the screw and use the Phillips screwdriver to screw the two wooden pieces together.



4- Remove the three plastic rings on the end of the pole, one at a time, carefully using a twisting motion if necessary to remove each piece.



5- Insert the clear plastic sleeve onto the pole, pushing it up to the knob end.



6- Return the three plastic rings to the end of the pole in the same order that they were removed.

Your pole is now assembled and ready to use.